

# Wood Care Instructions

---



HAND WASH

PORDAMSA's wood products are safe for food contact. All products have a mineral oil finish suitable for foodstuffs. As wood is a porous material, it has to be used and maintained with care.

## CLEAN USE HAND RENTED

- Wooden products are not suitable for washing machines.
- After each use, clean the item with a non-abrasive sponge with neutral soap and warm water. Remove the detergent with a humid mop and dry the item with a clean towel.
- When the product has only been used on dry foodstuffs, it is enough to clean the surface with a damp cloth and dry it immediately.
- For better care, do not submerge the products in water and store them in a dry place.

## USE

- It is advisable to apply mineral oil to the wooden items to prevent them from becoming crooked. Make sure you use mineral oil suitable for foodstuffs. To apply it, let the oil on the wood for 1 hour, then remove the excess with a paper towel or a soft sponge.
- Frequent reconditioning of the wood material with mineral oil, vegetable or food oil will guarantee a longer life of the product. Avoid direct sunlight and do not place it under a heat lamp or on a hot plate.
- Due to the characteristics of natural wood, the colour may vary.

**PORDAMSA®**

DESIGN FOR CHEFS